



MAGNETIC TOW LIGHTS



Thank you for your purchase of
Magnetic Tow Lights.


For additional product information, please
visit **CroftTrailer.com**.

HOOK UP PROCEDURES

For Magnetic Tow Light models **1481B**,
1481BKIT, **LED1481B**, & **LED1481BKIT**

1. Place **Magnetic Tow Lights** on
towed vehicle or equipment.
2. Once lights are in place, run
connecting wire along the side of
the towed vehicle to the towing
vehicle trailer light connector.
Connect the magnetic tow light to
the towing vehicle's connector.
3. Wrap the excess connecting wire
between lights and connector,
then secure to the towed vehicle.

Croft Trailer Supply | (800) 426-8159



COMMON TRAILER WIRING PROBLEMS

1. Trailer not properly grounded.
2. Trailer not wired to industry standards.
3. Open filament in light bulb.
4. Wires open or shorted.
5. Corrosion on ground between light and mounting bracket.

NOTE: Always check all hitch and wiring connections before towing!

Procedures work on both incandescent & LED lights.



CROFT TRAILER SUPPLY

(800) 426-8159 | www.CroftTrailer.com

Kansas City, MO
(816) 483-7274

Olathe, KS
(913) 780-1818

Lee's Summit, MO
(816) 525-9355

Smithville, MO
(816) 532-8900